VersaPro® 80% Gas Furnace Service Manual



Read this manual carefully before installation and keep it where the operator can easily find it for future reference.

Due to updates and constantly improving performance, the information and instructions within this manual are subject to change without notice.

Version Date: **April 9**, 2025 Please visit www.mrcool.com/documentation to ensure you have the latest version of this manual.



Table of Contents

1	Key to Symbols and Safety Instructions	4
1.1	Key to Symbols	4
1.2	Safety	4
<u> </u>	Tranklaskastina	6
	Troubleshooting	-
2.1	Electrostatic Discharge (ESD) Precautions	6
2.2	Resetting From Lockout	6
3	Error Codes	7
3.1	No Flash and No Fan (System Does Not Start Normally)	7
3.2	E7 System Lock-Out due to Failed Ignition E8 System Lock-Out due to too Many Flame Dropouts	10
3.3		12
3.4		12
5.4	E2 Low Pressure Switch Stuck Open E4 Pressure Switch Cycle Lockout	
	E3 High Pressure Switch Stuck Open	14
3.5	E5 Limit/Rollout Switch Open Less than 5 Mins	
	E6 Limit/Rollout Switch Open More than 5 Mins	16
3.6	Pr Incorrect Polarity of L1/L2	20
3.7	FL Low Flame	21
App	pendix A - Sequence of Operation	22
Two	Stage Controller Logic	22
41	Heating Modes	23
	A1.1 Low Fire Heating Mode Logic (only W1 signal):	23
	A1.2 High Fire Heating Mode Logic (W1+W2 Signal):	24
42	Ignition Failure and Reignition Sequence	25
43	Requirements for refrigerant leakage sensors	26

1 Key to Symbols and Safety Instructions

1.1 Key to Symbols

Warnings



Warnings in this document are identified by a warning triangle printed against a grey background.

Keywords at the start of a warning indicate the type and seriousness of the ensuing risk if measures to prevent the risk are not taken.

The following keywords are defined and can be used in this document:

- DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION indicates a hazardous situation which, if not avoided, could result in minor to moderate injury.
- NOTICE is used to address practices not related to personal injury.

Important information



This symbol indicates important information where there is no risk to people or property.

1.2 Safety

Please read all instruction in the manual and retain all manuals for future reference.



WARNING:

Untrained personnel (homeowners) may only clean and replace filters and replace fuses as required by basic maintenance. All other operations, including installation, repair, and service must be performed by a qualified installer, service agency, or the gas supplier.



WARNING: FIRE OR EXPLOSION HAZARD

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- ▶ WHAT TO DO IF YOU SMELL GAS:
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Leave the building immediately.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.



WARNING:

▶ Do not use this furnace if any part has been under water. A flood-damaged furnace is extremely dangerous. Attempts to use the furnace can result in fire or explosion. A qualified service agent must inspect the furnace and replace all gas controls, control system parts, and electrical parts that have been wet, or the furnace if deemed necessary.



WARNING: FIRE OR EXPLOSION HAZARD

- ► The furnace is designed and approved for use with Natural Gas and Propane (LP) Gas ONLY.
- DO NOT BURN ANY LIQUID FUEL OR SOLID FUEL IN THIS FURNACE.
- Burning any unapproved fuel will result in damage to the furnace's heat exchanger, which could result in Fire, Personal Injury, and/or Property Damage.



WARNING: FOLLOW ALL SAFETY CODES

Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes as well as the current editions of the National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the National Electrical Code (NEC) NFPA 70.



WARNING: FIRE, EXPLOSION

- Check entire gas assembly for leaks after lighting this appliance.
- Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in the Installation, Operation, and Maintenance Manual.



WARNING: FIRE, EXPLOSION, ELECTRICAL SHOCK, AND CARBON MONOXIDE POISONING HAZARD

▶ Failure to follow this warning could result in dangerous operation, serious injury, death, or property damage. Improper installation, adjustment, alteration, maintenance, or use could cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified service agency, local gas supplier, or your distributor for information or assistance.



WARNING: FIRE, EXPLOSION

See instructions for lighting/shutdown operation (as shown on a sticker directly on the inside of the furnace panel). Should the gas supply fail to shut off or if overheating occurs, shut off the gas valve to the furnace before shutting off the electrical supply.



WARNING: FIRE HAZARD

- The furnaces must be kept free and clear of insulating materials. Inspect surrounding area to ensure insulation material is at a safe distance when installing furnaces or adding insulation materials. Insulation materials may be combustible.
 - Maintain a 1 in. clearance from combustible materials to supply air ductwork for a distance of 36 in. horizontally from the furnace. See NFPA 90B or local code for further requirements.
- ► These furnaces SHALL NOT be installed directly on carpeting, tile, or any other combustible material other than wood flooring. In downflow installations, field supplied floor base MUST be used when installed on combustible materials and wood flooring. Special base is not required when this furnace is installed on industry standard Coil Assembly matching correct furnace width.



WARNING:

This product can expose you to chemicals including Lead and Lead components, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



CAUTION: CUT HAZARD

 Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

2 Troubleshooting



WARNING: FIRE, EXPLOSION AND ASPHYXIATION HAZARD

Installation and service must be performed by a qualified service agency or the gas supplier.

Refer to the troubleshooting charts and associated figures on the following pages for assistance in determining the source of unit operational problems. The diagnostic LED blinks to assist in troubleshooting the unit. The number of blinks refers to a specific code.

2.1 Electrostatic Discharge (ESD) Precautions

NOTICE:

 Discharge body's static electricity before touching unit. An electrostatic discharge can adversely affect electrical components.

Use the following precautions during furnace installation and servicing to protect the integrated control module from damage. By putting the furnace control and the person at the same electrostatic potential these steps will help avoid exposing the integrated control module to electrostatic discharge. This procedure is applicable to both installed and uninstalled (ungrounded) furnaces.

- Disconnect all power to the furnace. Do not touch the integrated control module or any wire connected to the control prior to discharging your body's electrostatic charge to ground.
- 2. Firmly touch a clean unpainted metal surface of the furnace away from the control. Any tools held in a person's hand during grounding will be discharged.
- Service integrated control module or connecting wiring following
 the discharge process in step 2. Use caution not to recharge your
 body with static electricity; (i.e. do not move or shuffle your feet,
 do not touch ungrounded objects, etc.). If you come in contact with
 an ungrounded object, repeat step 2 before touching control or
 wires.
- 4. Discharge your body to ground before removing a new control from its container. Follow steps 1 through 3 if installing the control on a furnace. Return any old or new controls to their containers before touching any ungrounded object.


2.2 Resetting From Lockout

Furnace lockout results when a furnace is unable to achieve ignition after three attempts. Refer to the troubleshooting chart on the following pages for assistance in determining the source of unit operational problems. The red diagnostic LED blinks to assist in troubleshooting the unit. If the furnace is in "lockout" it will (or can be) reset in any of the following ways.

- Automatic reset. The integrated control module will automatically reset itself and attempt to resume normal operations following a one hour lockout period.
- 2. Manual power interruption. Interrupt 115 volt power to the furnace for 1 20 seconds.
- 3. Manual thermostat cycle. Lower the thermostat so that there is no longer a call for heat for 1 20 sec.

3 Error Flash Codes

3.1 No Light and No Fan (System Does Not Start Normally)



No Light and No Fan (System Does Not Start Normally) Figures & Tables




Figure 1

- 1. Power off.
- 2. Press in the door switch.



3. Use a multi-meter to measure the resistance. If it is 0 Ω , then the door switch is ok.

Figure 2



Figure 3




Figure 4




Figure 5




Figure 6




Figure 7





Figure 8

3.2 E7 (System Lock-Out due to Failed Ignition) E8 (System Lock-Out due to too Many Flame Dropouts)



E7 (System Lock-Out due to Failed Ignition) E8 (System Lock-Out due to too Many Flame Dropouts)

Figures & Tables




Figure 9




Figure 10

	Manifold Gas Pressure
Natural Gas	3.5 in. W.C.
Propane Gas	10 in. W.C.

Table 1 Manifold Gas Pressure




Figure 11





Figure 12

	Inlet Gas Supply Pressure				
Natural Gas	Minimum: 4.5 in. W.C. Maximum: 10.5 in.				
Propane Gas	Minimum: 11.0 in. W.C.	Maximum: 13.0 in. W.C.			

Table 2 Inlet Gas Supply Pressure

3.3 E1 (Low Fire Pressure Switch Stuck Closed)



E1 (Low Fire Pressure Switch Stuck Closed)

Figures





Figure 13



Figure 14

3.4 E2 (Low Pressure Switch Stuck Open) E4 (Pressure Switch Cycle Lockout) E3 (High Pressure Switch Stuck Open)



- E2 (Low Pressure Switch Stuck Open) E4 (Pressure Switch Cycle Lockout) E3 (High Pressure Switch Stuck Open)

Figures



The pressure switch that you are checking in this step depends on the number of LED flashes. Refer to the specific flashes and their descriptions above.




Figure 15



Figure 16




Figure 17





Figure 18

3.5 E5 (Limit/Rollout Switch Open Less than 5 Mins) E6 (Limit/Rollout Switch Open More than 5 Mins)



E5 (Limit/Rollout Switch Open Less than 5 Mins) E6 (Limit/Rollout Switch Open More than 5 Mins)

Figures & Tables




Figure 19






Figure 21




Figure 22

Model			40A	60B	80B	80C	100C	120D
Rollout switch - resettable – °F					30	00		
Inlet High Temperature Limit switch - fixed	Off/On	°F	150/120	150/120	150/120	150/120	150/120	150/120

Table 3

Figure 20

5 Airflow Data


Air Delivery - CFM without filter

FURNACE SIZE	SPEED	STATIC PRESSURE	0	0.2	0.4	0.6	0.8	1
		[SCFM]	1149	1121	1160	1153	1143	1169
	Н	Temp.Rise °F	26	27	26	26	26	26
	NALL	[SCFM]	999	1008	994	1030	990	972
	МН	Temp.Rise °F	30	30	30	29	30	31
40A	М	[SCFM]	799	777	797	782	828	809
40A	IVI	Temp.Rise °F	37	38	37	38	36	37
	ML	[SCFM]	600	611	622	611	577	632
	IVIL	Temp.Rise °F	/	/	/	/	/	/
	L	[SCFM]	450	483	460	469	437	454
		Temp.Rise °F	/	/	/	/	/	/
	н	[SCFM]	1301	1294	1313	1325	1301	1288
		Temp.Rise °F	34	35	34	34	34	35
	МН	[SCFM]	1101	1106	1103	1106	1077	828 809 36 37 577 632 / / / 437 454 / / 1301 1288 34 35 1077 1142 42 39 879 918 51 49 824 813 / /
	Temp.Rise °F 41	41	40	41	40	42	39	
60B	M	[SCFM]	901	899	889	886	879	918
OUB	IVI	Temp.Rise °F	50	50	50	50	51	49
	ML	[SCFM]	800	816	841	783	824	813
	IVIL	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	600	631	635	612	601	610
		Temp.Rise °F		/	/	/	/	/

FURNACE		STATIC						
SIZE	SPEED	PRESSURE	0	0.2	0.4	0.6	0.8	1
	Н	[SCFM]	1301	1294	1313	1325	1301	1288
	- 11	Temp.Rise °F	46	46	45	45	46	46
	МН	[SCFM]	1101	1106	1103	1106	1077	1142
	IVIII	Temp.Rise °F	54	54	54	54	55	52
800	N 4	[SCFM]	901	899	889	886	879	918
80B	М	Temp.Rise °F	/	/	/	/	/	/
	ML	[SCFM]	800	816	841	783	824	813
	IVIL	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	600	631	635	612	601	610
	L	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	1301	1297	1271	1251	1343	1240
	Н	Temp.Rise °F	46	46	47	48	44	48
	D 41.1	[SCFM]	1101	1113	1142	1141	1060	1168
	MH	Temp.Rise °F	54	54	52	52	56	301 1288 46 46 077 1142 55 52 79 918 / / 24 813 / / 01 610 / / 843 1240 14 48 960 1168 36 51 74 924 / / 98 863 / / 736 1733 13 43 199 1505 50 50 347 1336 55 56 154 1142 / / 81 1013 / / 881 1917 38 39 786 1771 42 42 543 1544 48 48 412 42 543 53 179
900	D 4	[SCFM]	901	855	905	938	874	924
80C	М	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	800	785	815	823	798	863
	ML	Temp.Rise °F	/	/	/	/	/	/
	L	[SCFM]	600	606	593	549	571	549
		Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	1751	1739	1742	1739	1736	1733
	Н	Temp.Rise °F	43	43	43	43	43	43
	МН	[SCFM]	1501	1516	1492	1500	1499	1505
		Temp.Rise °F	50	49	50	50	50	50
1000	М	[SCFM]	1351	1351	1364	1356	1347	1336
100C		Temp.Rise °F	55	55	55	55	55	56
	D 41	[SCFM]	1151	1154	1152	1132	1154	1142
	ML	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	1001	995	996	982	981	1013
	L	Temp.Rise °F	/	/	/	/	/	/
		[SCFM]	1951	1910	1896	1929	1981	1917
	Н	Temp.Rise °F	38	39	39	39	38	39
		[SCFM]	1751	1775	1749	1772	1786	1771
	MH	Temp.Rise °F	43	42	43	42	42	42
1200	D 4	[SCFM]	1501	1570	1575	1569	1543	1544
120D	М	Temp.Rise °F	50	48	47	48	48	48
		[SCFM]	1348	1420	1410	1416	1412	1400
	ML	Temp.Rise °F	55	53	53	53	53	53
	,	[SCFM]	1148	1210	1196	1174	1179	1175
	L	Temp.Rise °F	/	/	/	/	/	/

3.6 Pr (Incorrect Polarity of L1/L2)

Troubleshooting Chart



Figures





Figure 23

NOTICE:

► Please refer to the wiring diagram to confirm whether the connection is normal. Please check whether the input power ground wire is correctly and reliably connected to the machine.

3.7 FL (Low Flame)



Appendix A - Sequence of Operation

Two Stage Controller Logic

A1. There are two heating modes:

 ${\sf A1.1\,Low\,Fire\,Heating\,Mode:\,Only\,W1\,signal}$

A1.2 High Fire Heating Mode: Both W1 and W2 signal



If you are using a single stage thermostat, only a W1 signal will be sent. In this scenario, the furnace will upstage from low to high fire via a timing sequence. The time delay is set via the S1-1 & S1-2 dip switches on the control board.

A2. If the furnace fails to ignite, there is a separate logic for the re-ignition sequence.

A1 Heating Modes

A1.1 Low Fire Heating Mode Logic (only W1 signal):




Figure 24

- When there is a call for heat (W1), the inducer will start on HIGH speed and the low pressure switch closes. This will last for **15s**.
- Inducer will turn to low speed and ignitor will energize. This preheating sequence lasts for **17s**.
- After preheating, gas valve opens and the burners light. The ignitor will turn off after **3s**.
- 4 There is 30s time delay before blower motor starts.
- 5 The system is working properly.
- When there is no call for heat (no W1 call) and no flame is sensed, post-purge begins. This will last for **15s**.
- There is a fan delay to dissipate heat in the system. This time depends on the dip switch S1-3 & S1-4. The default time is **180s**.

A1.2 High Fire Heating Mode Logic (W1+W2 Signal):




Figure 25

- When there is a call for heat (W1), the inducer will start on HIGH speed and the low pressure switch closes. This will last for **15s**.
- Inducer will turn to low speed and ignitor will energize. This preheating sequence lasts for **17s**.
- After preheating, gas valve opens and the burners light. The ignitor will turn off after **3s**.
- Before gas valve, inducer, pressure switch turn to high stage, there is a **5s** delay.
- (4)+(5) There is a time delay of **30s** before blower motor starts.
- (6) The system is working properly in high stage.
- When there is no call for heat, there is a time delay before inducer shuts down. This will last for **15s**.

- 8 The blower motor will run at high speed for **30s** for fan delay.
- There is a fan delay to dissipate heat in the system. This time depends on the dip switch S1-3 & S1-4. The default time is **180s**.

A2 Ignition Failure and Reignition Sequence

If the furnace fails to ignite, there is a separate logic for the re-ignition sequence:




Figure 26

- When there is a call for heat (W1), the inducer will start on HIGH speed and the low pressure switch closes. This will last for **15s**.
- Inducer will turn to low speed and ignitor will energize. This preheating sequence lasts for **17s**..
- After preheating, gas valve opens and the burners light. The ignitor will turn off after **3s**.
- (4) The gas valve will open for **4s** if there is no flame.
- 5 The inducer will run at high speed for **60s**.
- 6 Test of low pressure switch.
- 7 Preheating occurs for **27s**.
- After preheating, gas valve opens. The ignitor will turn off after **3s**. After two failed ignition attempts, system will lock out.


A3 Requirements for refrigerant leakage sensors

	W2	DELA	Υ				
	DIP	SW	NOMINAL				
	S1-1	S1-2	(MINUTES)				
	*OFF OFF		OFF				
			10				
	OFF	ON	AUTO				
	ON	ON	20				


HEAT OFF DELAY							
	DIP	SW	NOMINAL				
S	2-1	S2-2	(SECONDS)				
*0)FF	OFF	90				
(NC	OFF	120				
С	OFF ON		150				
1			180				

	C00	L OFF	DELAY				
	DIP	SW	NOMINAL				
	S2-3	S2-4	(SECONDS)				
	*OFF	OFF	60				
	ON OFF OFF ON		90				
			120				
	ON	ON	150				

Option Switch Positions



Control Board



Requirements for refrigerant leakage sensors



WARNING:

According to the safety requirements of UL 60335-2-40 on combustible refrigerant A2L, when the gas furnace is used with coil and the new type of combustible refrigerant is used in the coil, the unit must be equipped with the refrigerant gas detection sensor to monitor the refrigerant concentration around the unit in real time to prevent the danger of abnormal refrigerant leakage.

Refrigerant gas detection sensors are manufactured under the coil manufacturing label and must be installed by a qualified local gas supplier, distributor or service organization.

If the refrigerant gas detection sensor is not installed or is incorrectly installed, it does not meet the requirements of current regulations and cannot effectively warn of an emergency, which may cause personal injury. Therefore, follow the instructions provided in the manual.

Installation of refrigerant gas detection sensor

For the use of our coil unit, please connect the refrigerant gas sensor cable terminal to the CN30 interface, as shown in "Gas Furnace Control Module in Picture 32", and move the drive plate SW1-2 to the "ON" position. Refer to the coil manual for installation locations of refrigerant gas sensors.

Operation indication of refrigerant gas sensor

When the sensor detects a refrigerant leak, the unit will respond according to the following rules.

LED2 Number of green flashes	Fault location	Fault cause	Unit response & handling method
1	The refrigerant sensor communication fails	The communication with the refrigerant sensor fails for 2 minutes or the refrigerant sensor is faulty	The LED2 indicator of the driver board blinks green once, and the Y signal is disconnected to stop cooling. Contact your distributor to check the sensor.
2	Refrigerant concentration exceeds the limit alarm value	The pipe is damaged or the refrigerant leaks	The green light of the drive board LED2 flashes twice, disconnect the Y signal, stop the refrigeration, and the fan in the unit will continue to run until the refrigerant concentration is detected to decrease to a safe value. Maintain ventilation and avoid open flames. Contact the distributor to check the unit.
3	Forget the dip reminder	The sensor is connected and communication is normal, but SW1-2 is in the "OFF" position	LED2 of the driver board blinks green three times Check whether SW1-2 is in the ON position
4	Expiration reminder	The sensor expires or is faulty. Procedure	The LED2 indicator of the driver board blinks green four times to turn off the Y signal and stop cooling. Contact your distributor for a new refrigerant detection sensor.